

| Item no.: | Bending 90°- 180° | Angle Height | kg |
|-----------|---|-----------------------------|-----|
| 91541 | Disc-Bender DB 41 Single | ca. 8 – 40 mm (0,31"-1,57") | 0,9 |
| 91542-1 | Disc-Bender DB 42 Combi | ca. 8 – 40 mm (0,31"-1,57") | 2,6 |
| 91541S2 | Disc-Bender DB 41 S2 Single | ca. 8 – 40 mm (0,31"-1,57") | 1,0 |
| 91542-1S2 | Disc-Bender DB 42 S2 Combi | ca. 8 – 40 mm (0,31"-1,57") | 2,7 |
| 91547-1 | Adapter to connect two single Disc-Benders DB 41 | | |
| 91547-1S2 | Adapter to connect 2 single Disc-Benders DB 41 S2 | | |

Max. thickness of material

| | copper/zinc/aluminium | up to | 1,00 mm/19ga | |
|--|------------------------|-------|---------------|--|
| | galvanized steel | up to | 0,75 mm/21ga | |
| | stainless steel/Uginox | up to | 0,50 mm/24ga | |
| Angle Height | | | | |
| | min. angle height | ca. | 8 mm (0,31") | |
| | max. angle height | till | 40 mm (1,57") | |
| Note: depending on the material data might be different, m | | | | |

Note: depending on the material data might be different, max. bending heights depending on radius.

Max Draenert Apparatebau GmbH & Co. KG Gutenbergstrasse 15-17 D-73779 Deizisau Phone: +49-(0)7153-82170 Fax: +49-(0)7153-821766 E-mail: info@dracotools.com



Manual Disc-Benders



Way of working:

a. Because there is no adjustment work necessary you can start right away. Place bender on the 90° angle leg.



- b. You will notice that the convenient space of the guiding roller enables the uncomplicated placement of the tool
- Move the bender forth and back and push slightly down till requested angle is reached C. (max. 180°).



You achieve a perfect result without damage to painted or coated metal.

Draco's professional tip: when going through the sheet metal, please go all the way down (till the end) and also all the way back (till the beginning) to get the best result.

Information concerning special edition model S2:

DB 41 S2 with swiveling roller was specially designed for placing the tool easy in work pieces that are difficult to access because of too little space. By pressing the black button the locking mechanism will be released, by pressing it again it will snap at desired place.

Push button to release locking mechanism





Fax:

Push button again to lock in place

Upgrade your single Disc-Bender to a Combi Disc-Bender:

Connect two single Benders to a Combi Bender by using an adapter. Long and straight sheet metal will be easily bend. Adapter can be easily screwed on and off again.

91547-1: Adapter to connect two Disc-Bender DB 41 # 91547-1S2: Adapter to connect two Disc-Bender DB 41 S2





Max Draenert Apparatebau GmbH & Co. KG Gutenbergstrasse 15-17 D-73779 Deizisau

+49-(0)7153-82170 Phone: +49-(0)7153-821766 info@dracotools.com E-mail:

